

# Work Order ID 60636

Thursday, July 15, 2010 10:31:38 AM



Page 1

Item ID: D350-766-015

Accept



Setup Start



Revision ID:

Item Name: Interior Trim, Canopy Post

Stop



Start Date: 7/15/2010 Start Qty: 1.00



Cust Item ID:

Required Date: 7/22/2010 Req'd Qty: 1.00



Customer:

Reference:

Approvals:

Process Plan:

*R*

Date: 10-7-15 Tooling:

Date:

Run Start



QC:

Date: SPC (Y/N):

Date:

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
IIN-D350-766	C

100		0.00							
	DOCUMENT CONTROL								
DC	Memo	0.00							
Document Control	Photocopy bluefile and create labels per PPP D350-766-015 CHG001								

*5/10/12/16*

*AJ for BG 10/07/16*

110	Pick Kit	0.00							
Packaging	Memo	0.00							
Packaging									

*10.7.26 (30) SL*

120	QC4- 100% Inspect kits for completeness	0.00							
QC	Memo	0.00							
Quality Control									

*5/10/12/16*

*(70)*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

**Work Order ID 60636**

Thursday, July 15, 2010 10:31:38 AM



Page 2

Item ID: D350-766-015

Accept



Setup Start



Revision ID:

Item Name: Interior Trim, Canopy Post

Stop



Start Date: 7/15/2010 Start Qty: 1.00



Cust Item ID:

Required Date: 7/22/2010 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_  
QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Run Start



Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130 	Packaging	0.00							
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-766-015 Location: _____ PPP Rev: <u>PPART</u>								
140 	QC21- Final Inspection - Work Order Release	0.00							
QC	Memo	0.00							
Quality Control									

10/07/28 (1)10/07/28 (1)M 10-7-28 (1)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

# Picklist Print

Thursday, July 15, 2010 10:31:44 AM

Page 1

Work Order ID: 60636

Parent Item: D350-766-015

Parent Item Name: Interior Trim, Canopy Post






Start Date: 7/15/2010

Required Date: 7/22/2010

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP RevA: New issue DD verified by:EC

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D3946-1  Panel, Center Post		Manufactured	No			110	Each	0.0000	1	1			
D3947-1  Panel, Upper LH Post		Manufactured	No			110	Each	1.0000	1	1			
				<u>Location</u>			<u>Loc Qty</u>		<u>Loc Code</u>				
				ST150			1						
				55355			1						
D3947-2  Panel, Upper RH Post		Manufactured	No			110	Each	1.0000	1	1			
				<u>Location</u>			<u>Loc Qty</u>		<u>Loc Code</u>				
				ST150			1						
				55356			1						
D3947-3  Panel, Lower LH Post		Manufactured	No			110	Each	1.0000	1	1			
				<u>Location</u>			<u>Loc Qty</u>		<u>Loc Code</u>				
				ST150			1						
				55357			1						
D3947-4  Panel, Lower RH Post		Manufactured	No			110	Each	0.0000	1	1			

B60632 10/7/2010

10-7-2010

10-7-2010

10-7-2010

60633 10/7/2010

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: \_\_\_\_\_ PAR #: \_\_\_\_\_ Fault Category: \_\_\_\_\_ NCR: Yes No DQA: \_\_\_\_\_ Date: \_\_\_\_\_

Resolution: \_\_\_\_\_ Disposition: \_\_\_\_\_ QA: N/C Closed: \_\_\_\_\_ Date: \_\_\_\_\_

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

**NOTE:** Date & initial all entries

#### 4.0 WEIGHT AND BALANCE

The following is the weight increase associated with the Interior Trim Kits. Be sure to subtract the weight of any parts removed.

Installation	Weight	LATERAL		LONGITUDINAL	
		Arm	Moment	Arm	Moment
<b>D350-766-011</b> Interior Trim Kit (Aft Bulkhead Trim Kit)	13.2 lb 6.0 kg	0 in 0 m	0 in-lb 0 m-kg	113 in 2.87 m	1492 in-lb 17.2 m-kg
<b>D350-766-013</b> Interior Trim Kit (Ceiling Trim Kit)	11.0 lb 5.0 kg	0 in 0 m	0 in-lb 0 m-kg	91 in 2.31 m	1001 in-lb 11.6 m-kg
<b>D350-766-015</b> Interior Trim Kit (Canopy Post Trim Kit)	5.2 lb 2.4 kg	0 in 0 m	0 in-lb 0 m-kg	42 in 1.07 m	218 in-lb 2.6 m-kg
<b>D350-766-021</b> Interior Protector Kit (Aft Baggage Protector Kit)	14.3 lb 6.5 kg	2.77 in 0.07 m	39.6 in-kg 0.46 m-kg	168 in 4.27 m	2402 in-lb 27.8 m-kg

#### 5.0 PARTS LIST

Qty -011	Qty -013	Qty -015	Qty -021	Part Number	Description
X				D350-766-011	INTERIOR TRIM KIT (AFT BULKHEAD TRIM KIT)
	X			D350-766-013	INTERIOR TRIM KIT (CEILING TRIM KIT)
		X		D350-766-015	INTERIOR TRIM KIT (CANOPY POST TRIM KIT)
			X	D350-766-021	INTERIOR PROTECTOR KIT (AFT BAGGAGE PROTECTOR KIT)
1				D3655-1	PANEL
1				D3655-3	PANEL
	1			D3656-1	PANEL
	1			D3656-3	PANEL
			1	D3889-041	PANEL, FLOOR
			1	D3890-041	PANEL, WALL
			1	D3891-041	PANEL, FWD LH
			1	D3891-042	PANEL, FWD RH
			1	D3944-1	PLACARD
			4	D3945-041	BRACKET
		1		D3946-1	PANEL, CENTER POST
		1		D3947-1	PANEL, UPPER LH POST
		1		D3947-2	PANEL, UPPER RH POST
		1		D3947-3	PANEL, LOWER LH POST
		1		D3947-4	PANEL, LOWER RH POST
		3		D3948-041	PLATE, ANCHOR
		4		D3948-043	PLATE, ANCHOR
			14	AN525-10R7	SCREW
			4	AN525-10R9	SCREW
2				AN526-1032R12	SCREW
2				AN526-1032R20	SCREW
	15			AN526-1032R9	SCREW
			8	CCR264SS3-2	RIVET
	30			CCR264SS3-3	RIVET
8				CCR274SS3-4	RIVET
			8	CR3213-4-02	RIVET (OR M7885/2-4-02)
			12	CR3523-4-02	RIVET (OR M7885/4-4-02)
			16	CR3523-4-03	RIVET (OR M7885/4-4-03)
4	15		4	MS21059L3	NUTPLATE (OR MS21059-3)

• COPYRIGHT © 2008 BY DART AEROSPACE LTD. •  
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: C  
Date: 09.06.08